


Intermedio Union

 Tipo
Type


U

 Tubo in pollici
Imperial tube

 Tubo metrico
Metric tube

Codice Code	tubo tube T	LL	D	Min. Open E	H1	H	L	tubo tube T	Codice Code
U1	1/16	25.4	11	1.3	8	8	17.5		
U2	1/8	35.6	15.2	2.3	12	12	22.3		
U3	3/16	35.6	16	3	12	12	24.1		
U4	1/4	41.1	17.8	4.8	12	14	26.2	6	U M6
U5	5/16	43.2	18.5	6.3	14	17	28.2	8	U M8
U6	3/8	45.2	19.3	7.1	17	17	30.2	10	U M10
U8	1/2	51.5	21.8	10.4	22	22	31	12	U M12
U10	5/8	52.3	21.8	12.7	24	25	31.7	16	U M16
U12	3/4	53.8	21.8	15.7	27	30	33.3		
U14	7/8	55.4	21.8	18.3	30	32	35		
U16	1	65	26.4	22.3	36	38	40.4		

Intermedio di riduzione Reducing union

 Tipo
Type

RU

 Tubo in pollici
Imperial tube


 Tubo metrico
Metric tube

Codice Code	tubo tube T	tubo tube J	LL	D	D1	Min. Open E	H1	H	H2	L	tubo tube T	tubo tube J	Codice Code
RU 2-1	1/8	1/16	31.2	15.2	11	1.3	12	12	8	20.6			
RU 3-1	3/16	1/16	32.5	16	11	1.3	12	12	8	21.8			
RU 3-2	3/16	1/8	35.6	16	15.2	2.3	12	12	12	23.4			
RU 4-1	1/4	1/16	34.5	17.8	11	1.3	12	14	8	23			
RU 4-2	1/4	1/8	38.8	17.8	15.2	2.3	12	14	12	24.6			
RU 4-3	1/4	3/16	39.6	17.8	16	3	12	14	12	25.4			
RU 5-2	5/16	1/8	40	18.5	15.2	2.3	14	17	12	25.9			
RU 5-4	5/16	1/4	42.4	18.5	17.8	4.8	14	17	14	27.4	8	6	RU M8-M6
RU 6-1	3/8	1/16	35	19.3	11	1.3	17	17	8	25.4			
RU 6-2	3/8	1/8	41.1	19.3	15.2	2.3	17	17	12	26.9			
RU 6-4	3/8	1/4	43.4	19.3	17.8	4.8	17	17	14	28.5	10	6	RU M10-M6
RU 6-5	3/8	5/16	44.5	19.3	18.5	6.3	17	17	17	29.4	10	8	RU M10-M8
RU 8-2	1/2	1/8	45.4	21.8	15.2	2.3	22	22	12	28.5			
RU 8-4	1/2	1/4	47.2	21.8	17.8	4.8	22	22	14	29.4	12	6	RU M12-M6
RU 8-6	1/2	3/8	48.7	21.8	19.3	7.1	22	22	17	31	12	10	RU M12-M10
RU 10-6	5/8	3/8	49.5	21.8	19.3	7.1	24	25	17	31.7	16	10	RU M16-M10
RU 10-8	5/8	1/2	52.3	21.8	21.8	10.4	24	25	22	31.7	16	12	RU M16-M12
RU 12-4	3/4	1/4	49.5	21.8	17.8	4.8	27	30	14	31.7			
RU 12-6	3/4	3/8	51	21.8	19.3	7.1	27	30	17	33.3			
RU 12-8	3/4	1/2	53.8	21.8	21.8	10.4	27	30	22	33.3			
RU 12-10	3/4	5/8	53.8	21.8	21.8	12.7	27	30	25	33.3			
RU 16-8	1	1/2	63.5	26.4	21.8	10.4	36	38	22	40.9			
RU 16-12	1	3/4	63	26.4	21.8	15.7	36	38	30	40.4			

Adattatore intermedio S-LOK - 37° Union adaptor S-LOK - 37°

Tipo
Type

UA



Tubo in pollici
Imperial tube


Tubo metrico
Metric tube

Codice Code	tubo tube T	Tubo Tube 37°	LL	D	Min. Open E	H1	H	L	S	tubo tube T	Tubo Tube 37°	Codice Code
UA 1-2	1/16	1/8	25.4	11	1.3	12	8	23.4	5/16-24			
UA 2-2	1/8	1/8	32.5	15.2	1.5	12	12	25	5/16-24			
UA 2-4	1/8	1/4	35.3	15.2	2.3	12	12	28.5	7/16-20			
UA 4-4	1/4	1/4	35.6	17.8	4.3	12	14	30.2	7/16-20	6	6	UA M6-M6
UA 5-5	5/16	5/16	38.6	18.5	5.8	14	17	31	1/2-20	8	8	UA M8-M8
UA 6-4	3/8	1/4	39.9	19.3	4.3	17	17	32.2	7/16-20	10	6	UA M10-M6
UA 6-6	3/8	3/8	39.9	19.3	7.1	17	17	32.2	9/16-18	10	10	UA M10-M10
UA 8-8	1/2	1/2	46.2	21.8	10	22	22	35.6	3/4-16	12	12	UA M12-M12
UA 12-12	3/4	3/4	53.6	21.8	15.5	30	30	43.2	1/16-12			
UA 16-16	1	1	61.7	26.4	21.3	36	38	49	1-5/16-12			

Passaparte intermedio Bulkhead union

Tipo
Type

BU



Tubo in pollici
Imperial tube

Tubo metrico
Metric tube

Codice Code	tubo tube T	LL	C	D	Min. Open E	H1	H	L	L1	Foro paratia Wall bore mm	Spess paratia Wall thick max	tubo tube T	Codice Code
BU 1	1/16	31.7	17.3	11	1.3	8	8	23.8	13.5	5.2	3.1		
BU 2	1/8	51.5	31.2	15.2	2.3	12	12	38	24.6	8.3	12.7		
BU 3	3/16	53.8	32	16	3	14	12	40.4	25.4	9.9	12.7		
BU 4	1/4	57.9	33.5	17.8	4.8	17	14	42.9	25.4	11.5	10.2	6	BU M6
BU 5	5/16	61	35.6	18.5	6.3	17	17	46	28.5	13.1	11.2	8	BU M8
BU 6	3/8	62.5	35.6	19.3	7.1	19	17	47.5	29.4	14.7	11.2	10	BU M10
BU 8	1/2	71.4	41.9	21.8	10.4	24	22	51	31.7	19.4	12.7	12	BU M12
BU 10	5/8	72.9	42.7	21.8	12.7	27	25	52.3	32.5	22.6	12.7	16	BU M16
BU 12	3/4	79.2	47.5	21.8	16	30	30	58.7	35.6	25.8	16.8		
BU 16	1	96	57.5	26.4	23.3	41	38	71.4	45.2	33.7	19.1		